


Getting Started

Smart Hub Panel



vivint.SmartHome™

© 2018 Vivint, Inc. All rights reserved.

Vivint and its respective logos are registered trademarks or trademarks of Vivint, Inc. in the United States and other countries. All other trademarks are the property of their respective owners.

Getting Started Guide: *Version 2018 (for panel firmware version A.01 3.10.16 or higher)*

(System design and specifications are subject to change without notice. Information about system functionality and usage published in this document may vary from that for your system, depending on the installed firmware version. Screen images shown in this document may also vary from your system depending on the firmware version in use.)

Released (Updated): 8/23/2018

Document Part Number P/N: 77-600022-001 — Rev A.2

Control Panel Part Number P/N: VS-SH2000-000

Control Panel Compliance Model Number M/N: CP04

Other referenced Vivint products and their part numbers: *Door/Window Sensor V-DW11-345; Recessed Door Sensor V-DW21R-345; Motion Sensor V-PIR2-345; Secure Key Fob Remote V-SKEY1-345; Panic Pendant V-PANIC2-345; Glance Secondary Display V-SHD1; Doorbell Camera V-DBC2; Ping Indoor Camera V-CAM1*

Getting Started Guide

Welcome to Vivint Smart Home	1
Your Control Panel	2
Arm the Security System	3
Disarm the Security System	7
Emergency and Fire Protection	10
Smart Home Automation and Control	13
Add Users and Configure System Access	14
Remote Control with Web and Mobile Apps	16
Acknowledge and Clear Alert Notifications	17
Customize Your Panel and System	18
System Test	19
System Settings	20
Frequently Asked Questions (FAQs)	25
Regulatory, Service, and Warranty Information	26

Welcome to Vivint Smart Home

Thank you for your purchase and welcome to your new Vivint Smart Hub™ panel, our latest innovation in smart home security and automation technology.

This guide will help you quickly get to know and start using your control panel, as well as introduce you to many of the exciting state-of-the-art features and services offered by an integrated, intelligent Vivint Smart Home™ system. After reading, keep this guide in a handy location as a convenient reference.

Get support

For additional support — to learn more about how to use and troubleshoot your system through our online help resources, including video tutorials, articles, and detailed step-by-step instructions — please visit support.vivint.com.

To chat online with a Vivint representative — click this icon  at vivint.com.

To speak with Vivint Customer Care — call **1.800.216.5232**.

For faster assistance, make sure you are ready to:

1. Provide your account number.
2. Describe any relevant alert notifications.
3. Have access to your touchscreen panel.

Stay connected



Follow Vivint at twitter.com/vivinthome



Join Vivint at facebook.com/vivinthome



Follow Vivint at instagram.com/letsneighbor




Visit the Vivint Neighborhood at neighborhood.vivint.com

Your Control Panel

2

The Vivint Smart Hub monitors and manages all aspects of your integrated smart home system, including security sensors and automation devices. The touchscreen panel provides critical status information, alerts and event notification, and activity history; as well as access to video and audio communication, security arming/disarming, connected devices (locks, cameras, etc.) configuration and operation, and emergency features.



Touchscreen display

When the touchscreen background color is green, the security system is disarmed and ready to arm; when orange, the system is armed (stay or away). When the background is gray, the system is disarmed and is not ready to arm.

The top *status bar* shows date & time and weather information; and provides access to the emergency, networking, power, and sound features.



The bottom *navigation bar* indicates the system's security mode (armed or disarmed); and provides access to connected devices as well as the main **Menu**.



Downcast light indicator (system status)

When the downcast light is green, the security system is disarmed and ready to arm. When the light is orange, the security system is armed (stay or away). When the light is off, the system is disarmed and is not ready to arm.

Arm the Security System


Arming your system activates *monitoring* of the security sensors* (doors, windows, motion) in order to protect your home from intrusion. If a sensor is triggered when the system is armed (in either Stay or Away mode), an alarm results and the Monitoring Station contacts you through Vivint Live™ two-way voice communication via the panel or the mobile app.

Press the **Arming** icon , and then:

Arm your system to **Stay** mode by dragging to the left. The **Exit Delay** timer will silently count down 60[‡] seconds. Use Arm Stay when you want to be able to stay protected while at home. Arm Stay activates all perimeter sensors (i.e, door/window) *but not* the interior sensors.

OR

Arm to **Away** mode by dragging to the right. The **Exit Delay** timer will audibly count down 60[‡] seconds. Use Arm Away when you want to protect your home while you're away. Arm Away activates all of the security sensors *including* both interior sensors and motion detectors.



Silent Exit—Use this option to mute sounds during your exit this time.

Turn off Entry Delay—Use this option to turn off the delay timer, so the system arms immediately rather than counting down.

*Some 24-hour sensors such as smoke and CO detectors, panic pendants, and flood sensors are always active and can trigger an alarm 24x7x365.

‡Specific time values indicate the default setting.

Arm to Stay Mode

Arming to Stay Mode is for arming the home security service when people are staying in the house. Stay Mode arms the sensor-protected perimeter doors and windows while not arming the interior motion sensors or other interior doors. This allows your home to be occupied while the system is partially armed.

Stay Mode is used for arming the system after everyone is inside and no one is expected to enter or leave. When the system is armed in Stay Mode, you can move about your home without triggering the home security alarm. All the interior protection is off. But, if a sensor-protected perimeter door or window is opened, an alarm will sound.

Entry Delay in Stay Mode

When arming the system in Stay Mode, an Entry Delay option is shown on the Arming screen. This provides a way for an authorized person to enter using a sensor-protected door and disarm the system before an alarm is triggered.

This option is enabled, so the delay allows time for disarming the system after the door is opened. Disabling this option removes the delay, causing those entrances to instantly trigger the alarm in Stay Mode.

Quick Exit in Stay Mode

A configurable option called Quick Exit may be displayed on the Security Screen while the system is *armed in the Stay Mode*.

Pressing the Quick Exit button starts a timer to allow someone to exit or enter through a sensor-protected door programmed for delay without having to disarm the entire system. When the delay timer runs out, the system returns to the normal Stay Mode.

Silent Exit in Stay Mode

The following options for silencing the Exit Delay beeps and announcements are available when arming or disarming the system in Stay Mode.

- On the **Security** screen, a **Silent Exit** button is displayed.
- On the **Arming** screen, a **Silent Exit** button is displayed.
- On the **Exit Delay** screen, a **Silent Exit** button is displayed.

Selecting any of these options silences the beeps while the system is being armed. When arming, selecting this option doubles the length of the Exit Delay.

NOTE: To silence chimes and touchscreen feedback, press the **Mute** button on the panel's status bar.

Arm to Away Mode

Arming to Away Mode is for arming the system when everyone is leaving the house. Away Mode arms all sensor-protected perimeter doors and windows, interior motion sensors, interior glass break sensors, and any other sensor-protected interior doors. Your home must be unoccupied while the system is armed in Away Mode.

When the system is armed in Away Mode, you cannot move about the protected areas without triggering the home security alarm (applies only if the system is installed with interior motion detectors). An alarm also occurs if any sensor-protected door or window is opened or glass breakage is detected (applies only if glass break detectors are installed in your system).

Exit and Entry Delays in Away Mode

Certain sensors, such as a door sensor, have a delay before triggering an alarm. This provides a way for an authorized person to reenter the home without triggering an alarm.

- **Exit Delay:** Allows time to leave after arming the system.
- **Entry Delay:** Allows time to enter and disarm the system before an alarm is triggered. When arming the system in Away Mode, an **Entry Delay** option is shown on the **Security** screen. By default, this option is enabled, so the configured delay doors allow time for disarming the system after the door is opened. If you disable this option, the delayed alarm trigger is removed from all sensor -protected doors programmed for delay. Those entrances instantly trigger an alarm if they are opened in Away Mode.

NOTE: With the Entry Delay disabled, you must remotely disarm the system with a wireless remote device such as a key fob before entering.

Exit Delay Restart

The Exit Delay Restart option extends the Exit Delay *one time* if you need to re-enter the home. With the Exit Delay Restart option, when you re -enter the home *after* you have left, but *before* the Exit Delay timer expires, will restart the Exit Delay timer, giving you the full length of time to leave again.

NOTE: The Exit Delay Restart option works once *each time* the system is armed.

Silent Exit in Away Mode

Three options for silencing the beeps and announcements are available when arming or disarming the system in Away Mode.

- On the **Home** screen, a **Silent Exit** option is displayed.
- On the **Arming** screen, a **Silent Exit** option is displayed.
- On the **Exit Delay** screen, a **Silent Exit** option is displayed.

Selecting any of these options silences the Exit Delay while arming the system. When arming, selecting **Silent Control** doubles the length of the Exit Delay.

Quick Exit in Away Mode

A configurable option called Quick Exit may be displayed on the **Security** screen while the system is armed in the Away Mode. Pressing the **Quick Exit** button starts a timer to allow someone to exit or enter through a sensor-protected door configured for delay without having to disarm the entire system. When the delay timer runs out, the system returns to the normal Away Mode.

NOTE: If interior sensors are installed in the system in certain areas, do not violate those sensors when using the Quick Exit feature in Away Mode or an alarm will occur.



Auto Stay Mode

The system may have been configured by the Vivint Technician for Auto Stay Mode. If this option is on and the system is armed in Away Mode, if an exit/entry delay sensor is not triggered before the Exit Delay expires (no one left the home), the system automatically arms in Stay Mode instead of Away Mode.


Disarm the Security System

Disarming the security system deactivates *monitoring* of security sensors (but does not disable the sensors basic functionality) and prevents an alarm from being triggered. Disarming also shuts off any alarm currently in process.

Press the **Arming** icon  and disarm the system by dragging down and entering your personal code (PIN).



When armed in **Stay** mode, you can use the **Quick Exit** feature to let someone leave your home without triggering an alarm (and without having to disarm).



Additional Information: Disarming

To prevent your home security service from triggering an alarm, the security services need to be disarmed. Disarming turns off the home security protection part of the system for sensors that are not 24-hour sensors. Disarming also stops any type of alarm in process.

The system should be disarmed from Stay Mode before *exiting* your home. The system should be disarmed from Away Mode when *entering* your home. When disarming from the panel, enter a valid User PIN. A wireless key fob can also be used to disarm the system. Entering a User PIN is not required when disarming with a wireless key fob.

An **IMPORTANT** feature of the panel is its ability to warn you if an alarm *has* occurred while you were away. If an alarm was triggered while the system was armed, the alarm siren runs for a preset length of time then stops. When you enter to disarm the system, instead of sounding the normal Entry Delay beeps, the panel sounds fast beeps to warn you that an alarm has occurred.

WARNING: When you enter your home to disarm the system, if you hear fast repeated beeps instead of the normal Entry Delay beeps, use extreme caution! An intruder may be inside! Wait outside in an area visible to others and call law enforcement for assistance.

Quick Exit in Stay Mode

A system setting called Quick Exit may be displayed on the **Security** screen while the system is armed in the Stay Mode.

Pressing the **Quick Exit** button starts a timer to allow someone to exit or enter through a sensor-protected door programmed for delay without having to disarm the entire system. When the timer runs out, the system returns to the normal Stay Mode.

The Quick Exit option is on by default, and can be turned on or off by your Vivint Field Service Professional.

Disarm from Away Mode

The system should be disarmed from Away Mode when *entering* your home.

To disarm the system from Away Mode

1. Enter the home through a protected door.
2. The **Disarm** screen displays on the panel and the normal Entry Delay beeps sound.
3. Enter a valid User PIN to disarm the system.

If a Security Alarm Occurs

If an armed sensor is tripped while the system is armed in either Stay or Away Mode, an alarm occurs and the siren sounds. Delayed sensors start the Entry Delay to allow time to disarm the system. Instant sensors trigger the alarm right away. Most sensors trigger the alarm siren while some sensors may be set to trigger a silent alarm without sounding the siren.

NOTE: Temporarily muting the alarm siren

When the alarm siren is sounding, you can temporarily mute (turn off) the alarm siren by pressing any button on the panel interface. Pressing a button will mute the alarm siren for one second. The alarm siren will continue to sound until the proper disarming code is entered.

Alarm Siren

If the alarm is tripped while the system is armed, the panel sounds the alarm siren for a preset time. After the time expires, the alarm will stop sounding.

The system limits the number of times a sensor can re-trigger an alarm while the system is armed. The setting is one to six times per sensor, per arming period.

Alarm History

If an alarm has occurred while the system was armed, the Disarm screen shows the time and date of the alarm and the sensor(s) that triggered the alarm.

After the system is disarmed, the Alarm History screen appears. This screen shows the sensor(s) that have caused the alarm. If more than one sensor has been triggered, the display shows the order in which the alarms occurred.


The alarm history is automatically cleared the next time the security system is armed. You can also check the Clear Alarm History button to manually clear the alarm history.

NOTE: 24-hour fire and CO sensors that are still violated remain in the alarm history until those specific conditions are resolved.

Emergency and Fire Protection

The **Emergency** button (+) is found in the status bar of the display (right-hand side). Use this button in case of an emergency. Note that just pressing this button does not trigger an alarm.

When you press the button, the **Emergency** screen appears with three options:



Use the Emergency buttons

1. Press and hold the appropriate **Panic**, **Emergency**, or **Fire** button for at least 2 seconds until the alarm sounds.
2. The panel will send a signal immediately and a Monitoring Station representative will confirm the emergency through Vivint Live, which is the two-way voice communication at the panel. If no one at your home responds, the representative will call your emergency contacts. If the first emergency contact cannot be reached, Vivint will dispatch the authorities and continue trying to reach your emergency contacts.

About fire and carbon monoxide alarms

Your home may be installed with fire and carbon monoxide (CO) detectors as part of the comprehensive smart home security system. This safety feature is enabled 24 hours a day, 365 days a year.

In the event of a fire, smoke, or CO gas emergency, that specific detector automatically activates your security alarm. The detector will emit a loud alarm, and the panel will also emit a loud intermittent alarm to warn you. The panel alarm continues for four minutes or until you enter your PIN at the panel.

Additional Information: Fire Safety

Your home can be installed with fire and carbon monoxide detectors as part of Vivint's overall home security system. These security services are active 24 hours-a-day, 365 days a year.

In the event of a fire or poisonous CO gas emergency, the installed smoke and CO detectors automatically activate your security system. Not only will the smoke and CO detectors emit a loud alarm sound, the panel emits a loud intermittent alarm sound to warn you of the alarm. The fire alarm sound continues for four minutes or until you enter a User PIN at the panel. Your Vivint Field Service Professional can increase the amount of time the fire alarm sounds before automatically turning off.

If the Alarm Sounds

- Get out and stay out. Never go back inside for people or pets.
- If there is smoke, get low and escape under the smoke.
- Call the fire department from outside your home.

Automatic Fire Alarm

If the fire alarm sirens are sounding, do the following:

1. If flames and smoke are present, yell "FIRE!" to alert everyone else.
2. Evacuate all occupants from the house and call your local Fire Department from a safe location.

OR

1. If neither flames nor smoke are readily apparent, investigate the possible causes of the alarm.
2. Go to the panel and enter your PIN to stop the fire alarm.
3. Review the Alarm Memory (in the system activity history) to determine which sensor caused the alarm.
4. Go to the sensor and look for a reason the sensor was triggered.
5. Correct the condition that caused the detector to sense smoke.

Initiating a Fire Alarm Manually

Evacuating all occupants safely from the house is always the highest priority in the event of a fire. If you become aware of a fire *before* your detectors sense a problem, do the following:

1. Yell "FIRE!" to alert everyone else.
2. If the panel is easily accessible and the alarm has not activated, go to the panel and press the white lighted button, then press and hold down the **Fire** button on the touchscreen for at least 2 seconds. This action triggers the panel fire alarm.
3. Evacuate all occupants from the house and call your local Fire Department from a safe location outside your home.

Silencing a False Fire Alarm

If the fire alarm is sounding due to a detector sensing burnt food or some other non-emergency condition, do the following:

1. Silence the fire alarm sirens by entering your User PIN at the panel.
2. Review the Alarm Memory to determine which sensor caused the alarm. If the alarm restarts, there may still be smoke inside the detector's sensor. Re-enter your User PIN to stop the alarm from continuing to sound.
3. If the alarm restarts, there may still be smoke in the detector's sensor. Enter your user PIN again to stop the alarm. Fan the detector for 30 seconds to clear the detector's sensor chamber.
4. After the problem has been corrected, go to the Alarm History screen, check **Clear Alarm History**, and then press **OK**.

NOTE: Fire and CO sensors that are still violated cannot be cleared from the Alarm History screen until the device returns to normal operation. Carefully inspect your home for fire or heat if your fire alarm remains in alarm state.

Smart Home Automation and Control

The Vivint Smart Hub offers integrated, intelligent home automation and communication with smart connected devices* that can be accessed and controlled either directly at the panel or remotely with the Vivint apps.

At the panel, access your connected devices via the navigation bar.



Lock and unlock doors

At the **Home** or **Security** screen, press a door lock icon to see its current status, and to lock and unlock the door.

Adjust thermostat settings

Press the temperature icon to view thermostats, set custom schedules, and configure other settings.

Watch camera views and videos


Press the camera icon to access your cameras, view live video and clips, and configure settings such as motion detection, video recording, and more.

Control lights

Press the switch icon to access the outlet control modules, and turn on/off and dim lights.

View device status and configure settings

To view and configure settings for each of your devices, press the **Menu** icon > and then **Devices**. Select the desired device from the list.




*Note that smart home features and capabilities will vary depending on the devices installed, which can include: door locks, door and window sensors, motion sensors, key fobs, indoor and outdoor cameras, doorbell camera, thermostat, outlet control modules, water sensors, data storage, and more.

Add Users and Configure System Access


The primary admin user can add other users to your Vivint Smart Home system, like family members and trusted friends, and specify their access rights. Give them access at the panel or remotely through the apps. You can also customize user-specific access to your home with unique door lock PINs.

Add users and configure permissions

Press the **Menu** button > **Users** > and then **Add New User**.



At a **User** page*, you can grant permissions, assign PINs, and remove the user.



Invite users to control your system remotely

You can also grant (and revoke) remote access privileges to users so they can control your system remotely via the web and mobile apps. Once you've sent a remote access invitation, the recipient has 48 hours to accept it.

*For information about the Duress User and duress signals, see the *FAQ* page.

Duress User

The Duress User Code initiates a silent alarm for help by secretly sending a Duress report to the Vivint Central Station.

IMPORTANT: Use the Duress Code only if someone is forcing you to operate your security system against your will. When you use the Duress Code, a silent report is immediately sent to the Central Station and they will dispatch help.


The Duress User feature is disabled by default. Follow the steps below to enable the Duress User and specify its unique PIN code.

Set the Duress User Code

1. On the **Users** screen, press **Duress User**.
2. Toggle ON the **Enable Duress User PIN Code**.
3. Press **Duress PIN code**, enter a unique four-digit code for the new Duress User Code, and then press **Save**.

Remote Control with Web and Mobile Apps

You, and your invited users, can control your Vivint system from anywhere and anytime with a laptop, tablet, or smartphone using the Vivint Smart Home™ apps . The app interface closely resembles the panel display making it familiar and easy to use.



What you can do with the web and mobile apps

With the web app and mobile apps (for iOS and Android devices) you can:

- Arm and disarm the security system
- View system status and activity
- Add users and configure access
- Watch camera views and videos
- Lock and unlock doors
- Adjust thermostat settings
- Turn on/off and dim lights
- And more!

Download and install the mobile app

Go to the App Store (iOS) or Google Play (Android), search for the Vivint Sky app, and install it. You can also go to vivint.com/mobile to learn more.

Sign in to the web and mobile apps

At your web browser, go to vivintsky.com and enter your email and password. On your mobile device, open the app and enter your email and password.

Acknowledge and Clear Alert Notifications

Vivint continually monitors security sensors, smart home devices, and the panel itself to ensure optimal performance and communicate timely status information via the panel and apps. Whenever events or conditions are detected that require your attention, the panel displays an **Alert** notification (in the case of emergency alerts it also beeps) until the alert is acknowledged.



The following components/conditions are monitored and can trigger an alert:

- Input power to the panel
- Panel communications
- Sensor communications
- Panel tampering
- Sensor tampering
- Panel and sensor batteries

Acknowledge and clear alerts

When the **Alert** icon  displays, press the icon and read the alert in order to acknowledge it. After you acknowledge an alert, the panel will stop beeping.

You must resolve the issue that triggered the alert in order to completely clear it. For example, you must replace sensor batteries in order to clear a sensor's low battery alert.

View system messages


In addition to alerts, the panel can receive system messages about software updates, regional severe weather reports, etc.

When the **Message** icon  displays, press the icon and read the message. If the message is critical, such as a severe weather alert, the panel will display pertinent details and beep to further warn you of possible danger.

Customize Your Panel and System

You can easily customize the appearance and behavior of your control panel as well as how the entire Vivint Smart Home system interacts and communicates. Features and settings you can adjust to your own preference include display brightness and timeout, volume (separately for the panel, doorbell speaker, and other sounds), sensor-specific chimes, voice alerts, and more.

Press the **Menu** button > **Devices** > and then **Smart Hub**.



Configure and control your smart home devices

As mentioned on the *Smart Home Automation and Control* page, you can configure each of your system's connected devices and how they interact with each other, including video cameras, doorbells, door locks, sensors, lighting controls, thermostats, and more (depending on your installation). You can also use predefined and custom rules to optimize system-wide operation to best meet your specific needs.

Access and configure your devices from the panel or with the Vivint apps.



Even though your security system electronics is self-monitoring, it is still important to regularly test the system manually. The System Test is used to test each of the sensors in the system, as well as LED light indicators and the sounder. The Admin User PIN code is required to test the system.

IMPORTANT: Test your security system weekly to ensure continued protection and proper system operation.

To test the system

1. At the **Home** screen, press the main **Menu** in the lower right-hand corner of the touchscreen display.
2. Press **Security**, enter a valid user PIN, and then press **System Test**.
3. Follow the prompts to teach each sensor:
 - For door or window sensors, open and close the door or window.
 - For motion detectors, stay out of the protected area for five minutes, then walk through the area.
 - For portable sensors and wireless keypads, press a button.
 - For smoke, CO, or glass break detectors, press the detector's test button.
5. When all sensors have been tested, a confirmation screen appears.

NOTE: System Test *start* and *stop* test reports are sent to the Central Station.

The Vivint Technician who installed your system can also configure various system settings in order to customize the installation. This section describes each of the various settings, their default value, and other possible values.

Siren Run Time

If there is a burglary, panic (police), or emergency alarm, the panel sounds the siren for a preset time. After the time expires, the siren will stop sounding. (Auxiliary alarms run for an unlimited time.)

4 Minutes is the default. Other possible settings include:

- 8 Minutes
- 12 Minutes
- 16 Minutes
- Unlimited

Sensor Trigger Limit

The system limits the number of times a sensor can re-trigger an alarm while the system is armed. The setting is 1 to 6 times per sensor, per arming period.

2 Triggers is the default. Other possible settings include:

- 1 Trigger
- 3 Triggers
- 4 Triggers
- 5 Triggers
- 6 Triggers

Fire Alarm Run Time

If there is a fire or carbon monoxide alarm, the panel sounds the fire alarm for a preset time. After the time expires, the fire alarm will stop sounding.

4 Minutes is the default. Other possible settings include:

- 8 Minutes
- 12 Minutes
- 16 Minutes
- Unlimited

Exit Delay

The Exit Delay begins immediately after arming the system. The delay gives you time to exit through the designated exit/entry door without setting off the alarm.

During the Exit Delay time period, beeps sound; and faster beeps sound during the last 10 seconds.

NOTE: Arming remotely does not start an Exit Delay.

60 Seconds is the default. Other possible settings include:

- _____ Seconds, for _____ Door.

Entry Delays

The Entry Delay begins when the designated entry/exit door is opened while the system is armed. The delay gives you time to disarm the system before triggering the alarm. You must enter a User Code on the panel or Wireless Keypad before the Entry Delay time expires.

During the Entry Delay, beeps sound to remind you to disarm the system.

The system supports two different Entry Delays:

- Entry Delay #1 is for your primary entrance door. 30 Seconds is the default. Or, _____ Seconds, for _____ Door.
- Entry Delay #2 is for a secondary entrance (such as a garage door) and is usually set longer to give you time to get to the keypad and disarm the system. 30 Seconds is the default. Or, _____ Seconds, for _____ Door.

24-Hour Emergency Functions

Three 24-hour emergency functions — Panic, Fire, and Emergency — can be activated by pressing buttons on the Control Panel.

The installer can set which emergency buttons on the panel are active.

- Panic (Audible)
- Panic (Silent)
- Fire
- Emergency

Quick Arming

Quick Arming allows you to arm your system without having to enter a User Code.

When you press the **Stay** or **Away** button, the system will start to arm without requesting a User Code. The default setting is On.

- Off
- On

Quick Bypass

Normally sensors that are open at the time the system is armed will require force bypassing by entering your User Code. The system can be set so a User Code is not required to bypass open sensors when the system is armed. The default setting is Off.

- Off
- On

Quick Exit

The Quick Exit option allows you to start the Exit Delay while the system is armed. This allows you to exit the home without having to disarm and rearm the system.

When the Quick Exit option is on, a Quick Exit button will display on the security screen. Press the button to start the Exit Delay.

After Quick Exit, the system will fully re-arm in the mode that it was in before (Stay or Away Mode). The default setting is On.

- Off
- On

Auto Un-bypass

Normally, sensors manually bypassed with the User Toolbox will automatically have their bypasses removed when the system is disarmed. The system can be set so sensors that have been manually bypassed will stay bypassed until the bypass is manually removed. The default setting is On.

- Off
- On

Auto Stay

The Auto Stay option will change the arming mode if no one exits after arming the system in Away Mode. When the system is armed in the Away Mode the Exit Delay will begin.

With the Auto Stay option on, if a designated exit/entry door does not open and close during the Exit Delay, the system will arm in the Stay Mode instead of the Away Mode. The default setting is On.

Off

On

Exit Delay Restart

The Exit Delay Restart option will extend the Exit Delay one time if you need to re-enter the home. When the system is armed in the Away Mode or Stay Mode, the Exit Delay gives you time to exit without setting off the alarm. With the Exit Delay Restart option, re-entering the home after you have left, but before the Exit Delay timer expires, will restart the Exit Delay timer, giving you the full length of time to exit again.

The restart option only works once, each time the system is armed.

The default setting is On.

On

Off

Cancel Display

A "cancel" message will be sent to the Central Station if the system is disarmed within a preset period of time after an alarm is triggered. The system can be set to display that a cancel report was sent, or for higher security, the system can be set to not display the cancel message.

The default setting is On.

On

Off

Cancel Time

To limit responses to false alarms, a "cancel" message will be sent to the Central Station if the system is disarmed within a preset period of time after an alarm is triggered.

The alarm report is always sent, but it will be followed by a cancel report if you disarm the system within the preset time.

This option helps the Central Station to determine whether you accidentally caused the alarm or if the alarm report was caused by an intruder. It also lets the Central Station know that you have returned to the home. Even if a cancel message is sent, the Central Station will verify the alarm and possibly dispatch help. The cancel message may be processed by the Central Station at a later time depending on system configuration.

- 5 Minutes is the default. Or, _____ Minutes.

Dialer Delay

If an alarm occurs, the system will delay transmitting the alarm for a short time to allow you to disarm the system in case the alarm was accidentally tripped. The dialer delay reduces nuisance traffic to the Central Station and can prevent receiving fines that many cities impose when police respond to a false alarm. Your installer also can configure the system for no dialer delay.

NOTE: The dialer delay is also known as the *abort window*. It gives you time to disarm, but doesn't delay the siren from sounding. Disarming during the abort window can display a cancel message depending on the Cancel Display setting.

- 30 Seconds is the default. Or, _____ Seconds.

Two-way Voice

The system can connect with a Central Station operator so they can converse with people after an alarm.

The two-way voice option allows communication to and from the panel and the Central Station. Two-way voice communications will occur after the system has made its alarm report. Your installer sets which sensors can trigger the two-way voice option. The default setting is On.

- Off
- On

Frequently Asked Questions (FAQs)

Read these common questions to learn more about your system.

What should I expect in an alarm situation?

Burglary alarm, emergency, or fire alarm — Vivint will attempt to contact you through your panel via Vivint Live to confirm the alarm, ask for your verbal password, and determine the nature of the emergency. If no one answers, Vivint will call your first emergency contact. If no one is available to confirm the alarm, Vivint will dispatch the authorities and continue trying to reach your emergency contacts (unless prohibited by local regulations).

How do I send a duress signal?

The duress code is for situations when you need emergency personnel sent to your home but don't want to alert an intruder that you are sending a signal. For example, if you are being forced to re-enter your home and need to disarm your panel, you can use this code to stop the panel beeping while simultaneously alerting Vivint. When Vivint receives a duress code, we will immediately dispatch the police without attempting to contact you.

Press the **Arming** icon, press **Disarm**, and enter the duress code. A duress signal will be sent. Although the panel will be disarmed and appear normal, we will receive the signal and send help immediately. (When your system was installed, you were informed of the duress code. If you have forgotten your code, see the Duress User under User Settings, or call Customer Care.)

How do I change sensor batteries?

Occasionally the panel will display a "low battery" alert to indicate that a specific sensor or device needs to have its batteries replaced. Typically, this is a very quick and easy procedure. Simply go to the identified sensor (motion detector, door/window sensor, etc.), remove the cover and/or open it, replace the batteries, and then replace the cover or close the sensor. Once replaced, the "low battery" alert is cleared. For more information, you can also go to support.vivint.com to see video tutorials and how-to instructions on how to replace batteries for Vivint sensors and devices.

How do I manage my home online?

To manage your home online, go to vivintsky.com and log in with your email address and password. You can also access your system from the online account center by visiting account.vivint.com. Once logged in, click the **Control My Home** icon.

Regulatory, Service, and Warranty Information

For complete regulatory information, go to: support.vivint.com/fcc.

FCC and IC Regulatory Compliance Declarations

The complete FCC and Industry Canada (IC) Regulatory Compliance Declarations are posted online at the Vivint Support website. The full text of these notices is also provided below, as a convenient reference for anyone who installs, configures, or uses the system.

FCC Notice



CAUTION: Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules and Industry Canada (IC) license-exempt RSS standard(s). Operation is subject to these two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / television technician.

This product complies with FCC radiation exposure limits for an uncontrolled environment. Avoid operating this product at a distance less than 7.9 in (20 cm) from the user.

IC Notice (Avis D'Industrie Canada)

PRUDENCE: Changements ou modifications pourraient annuler le droit de l'utilisateur à utiliser l'équipement non autorisées.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre une énergie de radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions, il peut causer des interférences nuisibles aux communications radio. Cependant, il n'existe aucune garantie que des interférences ne se produiront pas dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la réception radio ou télévision, ce qui peut être déterminé en mettant l'équipement hors et sous tension, l'utilisateur est encouragé à essayer de corriger l'interférence par une ou plusieurs des mesures suivantes:

- Réorienter ou déplacer l'antenne de réception.
- Augmentez la distance entre l'équipement et le récepteur.
- Connecter l'équipement à une sortie sur un circuit différent de celui sur lequel le récepteur est branché.
- Consulter le revendeur ou un technicien radio / télévision expérimenté pour de l'aide.

Ce produit est conforme aux limites FCC d'exposition aux radiations pour un environnement non contrôlé. Évitez d'utiliser ce produit à une distance inférieure à 7,9 in (20 cm) de l'utilisateur.

FCC ID: 2AAAS-CP04

IC: 10941A-CP04

Service information

Your local Vivint Smart Home Pro™ technician is the person best qualified to service your system. Should your system require service due to ordinary wear and tear while under contract, we will repair or replace the equipment for free. Note that trip fees may apply.



IMPORTANT: THE INSTALLED EQUIPMENT MUST BE CHECKED BY A QUALIFIED VIVINT TECHNICIAN AT LEAST EVERY 3 YEARS.

There are no user-servicable parts inside the control panel. For service, repair, or product upgrades, contact Customer Care.

For all inquiries about the warranty and related service, call Vivint Customer Care at **1.855.819.8137**.

Warranty information

For the complete warranty and service plan, including details about terms and conditions, go to: support.vivint.com/product/policies.

Account information

Install date:

Service number:

